

Tuning the Ukulele



Included with the Ukulele will be an Electronic Tuner.

Clip it to the headstock of the Ukulele.

Turn it on by pressing the button.

Make sure that you see the letter U on the screen. If you see anything else, press the button to cycle through the other letters til you get to U.

Starting with the string closest to you – G – turn the tuner slowly

until the screen on the tuner turns green. Then repeat with the other strings – C, E, A.

When a ukulele is first being tuned, the will stretch so expect to retune a few til the string will hold the correct tuning. This will require some patience your part, but you've got this!

Happy Strumming!



strings
times

on